



« photo-optics »



standard « spot-optics »

How to replace the Scurion® optics :

1. Take off the glass (you need a torx-10-screwdriver) with the optics sticking on it.
2. With a knife blade you can gently detach the optics from the glass – i.e. the three white scotch dots.
3. Put the three scotch dots on the new optics (if they are not already there) and eventually remove the small protection films on the dots.
4. Place the new optics exactly on the small white spacer over the LED.
5. Put back the glass with only 2 screws and pay attention that the optics do not move.
6. Now turn on the light and check the light pattern of the spot against a wall (better ceiling) – you see immediately if the optics is tilted or shifted – the spot must be nice round and uniform.
7. When the light pattern is perfect – screw in the remaining screws – done!

PS : try not to lose the O-ring and the spacer ;-)